



Ty2[®] STRAP


Instructions for the Ladder Buckle using the SSP 482 manual tensioner



Thread one end of the Ty2 Strap through the middle of the buckle. Make a loop around one end and insert strap under the looped end.




Lead the end back through the middle of buckle. Pull away from buckle.




Repeat steps 1-4 with the opposite end. Pull tight. Allow a minimum of 10"-14" overlap for tensioner use.



Set brake on the bottom strap. Release



Place the top strap through the cutter and tensioner slot.



Hold handle and tension strap, allowing at least a 3" overlap from the buckle.



After tensioning, squeeze the handle again, to cut the strap, releasing the brake, and remove.

